



Отвод сегментный 0-45°

DN	0-45°	
	SDR17	SDR11
40	100	146
50	151	222
63	237	348
75	237	343
90	274	400
110	369	537
125	470	697
140	639	939
160	763	1 129
180	883	1 303
200	1 088	1 607
225	1 381	2 039
250	2 378	3 502
280	2 982	4 387
315	3 819	5 640
355	5 196	7 631
400	7 022	10 382
450	9 587	14 150
500	14 010	20 648
560	19 307	28 433
630	24 431	36 967



Отвод сегментный 46-90°

DN	46-90°	
	SDR17	SDR11
206		301
234		345
295		433
345		499
370		541
439		639
745		1 105
902		1 324
980		1 450
1 425		2 104
1 617		2 389
2 295		3 388
3 120		4 595
3 914		5 758
5 122		7 566
7 794		11 445
10 922		16 148
13 847		20 438
19 263		28 390
27 580		40 618
34 901		54 876




Тройник сегментный 90°

DN	Тройник 90°	
	SDR17	SDR11
63	366	538
75	516	745
90	675	987
110	810	1 178
125	1 015	1 506
140	1 276	1 874
160	1 567	2 318
180	1 852	2 734
200	2 283	3 372
225	2 898	4 279
250	3 962	5 834
280	5 591	8 224
315	6 788	10 488
355	9 742	14 500
400	15 122	22 358
450	19 172	28 298
500	25 683	37 852
560	38 612	56 864
630	48 861	72 308



Крестовина

DN	Крестовина 90°	
	SDR17	SDR11
366		699
516		969
675		1 282
810		1 531
1 015		1 957
1 276		2 436
1 567		3 014
2 015		3 554
2 847		4 384
3 820		5 563
5 011		7 585
6 776		10 691
9 631		13 033
15 777		18 597
22 201		29 066
30 553		36 788
44 811		49 208
60 115		73 924
79 397		94 001



Тройник сегментный 45°

DN	Тройник 45°	
	SDR17	SDR11
63	285	460
75	334	528
90	481	746
110	848	1294
125	1159	1773
140	1583	2382
160	2041	3073
180	2755	4122
200	4499	6566
225	5851	8559
250	7 730	11 307
280	9 585	14 023
315	13 008	19 296